

TWIN BENCHTOP WATER FILTERS

🔀 sales@waterfilter.com.au

**** 1300 70 1300

♥ 100 Frobisher St, Osborne Park WA 6017

www.wawaterfilters.com.au - www.waterfilter.com.au



X

×

\$85

SPECIFICATIONS

Fluorides

Chloramines

Replacement Filters Bundle

Dimensions: 270 W x 370 H x 130 D mm Flow Rate: 3 LPM Connects To: 1/2" Kitchen Faucet Spout Min. Working Pressure: 25 psi Max. Working Pressure: 125 psi Min. Operating Temperature: 0.6 °C Max. Operating Temperature: 38 °C

Note: Flush the system for a few minutes before use. This will remove non-toxic carbon fines and oxygen (air bubbles) from the new cartridges.

To ensure optimal performance, hygiene and to prevent build up of contaminants, we recommend that filters are not used any longer than 12 months.

However, replacement frequency depends on water quality and usage. Filters should also be changed when rated capacity is reached, or when flow becomes too slow.

Unlike an RO system, these systems will NOT reduce Total Dissolved Solids (TDS), or Calcium

\$209

\$125

If you are interested in a filter that removes TDS or hardness, consider our Reverse Osmosis (RO) systems.


Components are Tested and Certified by NSF International under NSF/ANSI Standard 42 for material requirements only.



Our systems are connected to your existing kitchen faucet and are supplied with an adaptor and a diverter to connect to your faucet.

DIY Installation

NOTE: An external thread on the faucet indicates a male fitting. An internal thread indicates a female fitting.





- 1. Find a convenient countertop location to place the filter system in reach of your faucet.
- 2. Unscrew the existing aerator from your faucet.
- 3. An external thread indicates a male fitting, while and interior thread indicates a female fitting.
- -With a female fitting, first screw the $\bar{\text{st}}$ and and adaptor, then the diverter.
- With a male fitting, screw on the diverter.